




How to Care for



Your Podium

Stainless Steel

Clean your stainless steel accents with stainless steel cleaner and a shop towel

Internal Drawer Tracks

Internal drawer tracks need to be tightened on average once a month, to keep the screws from loosening and falling off

Drawer Tracks

We spray your drawer tracks with White Lightning Grease[™] before we ship and we recommend spraying yours every 2 months

Wipe down your podium with soap & water using a microfiber towel

Surface

Locks

Give us a call to get a replacement lock, reset your combo lock, or order extra keys

Door

If your having issues with the small spring latch that connects to your door, feel free to give us a call for a replacement

Handles

Tighen all handles monthly

Rust

Rust is an important issue to address quickly. We recommend using Rust-Oleum[™] and touch up paint as preventative maintance

Casters

Don't roll your podium while the casters are locked

LED'S*

Don't charge the battery at the same time as running your LED's. Do not allow the battery to get wet

* if applicable

